



MODEL NO. 11.2741
LED Signal Stick
Complete with Controller

GENERAL INFORMATION

The LED Signal Stick alerts traffic in the direction they need to follow. The Signal Stick (Model No. 11.1041) comes complete with controller (Model No. 11.1000). The controller has an ON/OFF switch, Rotary switch and Speed Control Dial. **NOTE:** Sheilded wire must be grounded at the Controller. The LED Signal Stick has twelve flash patterns from which to choose:


- | | |
|----------------------------------|---------------------------|
| 1. Random Flash - (Patterns 2-7) | 7. Left 4 Right 4 |
| 2. Quad Flash 2-2 | 8. Center Out |
| 3. Quad Flash 4-4 | 9. Right * w/Double Flash |
| 4. Double Flash 2-2 | 10. Right |
| 5. Double Flash 4-4 | 11. Left * w/Double Flash |
| 6. Center 2 Outer 2 | 12. Left |

INSTALLATION INSTRUCTIONS

Use the L- brackets (included) to mount the LED Signal Stick. To install mounting bolts to the signal stick, remove 4 screws from the end cap and install the mounting bolts into the desired t-slot as shown in drawing, then re-install the end cap.

WIRING INSTRUCTIONS:

Black wire to Ground, Red wire to Positive +12V and Yellow wire to switch +12V (Optional). Yellow wire activates the signal stick in a Random Flash Pattern when +12v is applied. When operating signal stick with controller, All Signal Stick functions will override the Random Flash.



PRODUCTS COMPANY 804 East Hwy 248 Cassville, MO 65625
 U.S. and Canada Toll Free Numbers Phone: 800-641-4098 FAX: 800-526-1240
 E-mail: sales@able2products.com WEB: www.able2products.com